2.2

Valve banks type BWN and BWH with directional valves acc. to D 7470 A/1


Pressure $p_{max} = 350 \dots 450 \text{ bar}$ = 5 ... 30 lpm Flow Q_{max}

1. **General information**

The directional valves WN 1 or WH 1(2 and 3) type (acc. to D 7470 A/1) are mounted on sub-plates. These valve banks are laterally arranged between a connection block and an end plate, all held together and hydraulically connected via a tie rod. The connection block, with inlet for pressurised oil and outlet for the return, is available in differing versions: With/without pressure limiting valve or as an adapter to mount the valve bank on hydraulic power units. The galleries for pressurised oil and return run through all sub-plates and connect the mounted valves in parallel.


The valves are counted starting from the connection block. For more detailed data and notes concerning the individual valves refer to D 7470 A/1.

Directional valve bank into basic version




Order example and flow pattern symbol corresponding to the photo


BWN 1 A - 2/120 - FNGS - 1 - 1 - G 24



Directional valve bank for direct mounting at a compact hydraulic power pack Here e.g. HK 44/1 M - H 6,0 - A1/200 (acc. to D 7600-4)



Order example and flow pattern symbol corresponding to the photo



HAWE HYDRAULIK SE STREITFELDSTR. 25 • 81673 MÜNCHEN

D 7470 B/1

2. Available versions

For complete type overview ref. to section 7, page 23

2.1 Type coding and general parameter




Table 1: Basic type

144.0 11 246.0 1) po										
Coding	Valves acc. to D 7470 A/1	Pressure p _{max} (bar)	Flow Q _{max} (lpm)							
BWN 1 9)	WN 1	350 (300) ⁸)	5 (6) 8)							
BWH 1 9)	WH 1	450	8							
BWH 2	WH 2	350	15							
BWH 3	WH 3	350	30							

Table 2: Port size

Coding	1	2
Ports ISO 228/1 (BSPP)	G 1/4	G 3/8
Directional valve bank	BWN 1 BWH 1 BWH 2	BWH 3

Table 3: Actuation solenoid

G 12	12 V DC	
G 24	24 V DC	
WG 110	110 V AC	50 and
WG 230	230 V AC	60 Hz

For further voltage and notes ref. to see D 7470 A/1 sect. 2.2.2

2.2 Connection blocks and adapter plates

Type of insta	llation		Suited for				Coding Design	Pressure limiting va	alve Spring	Symbols			
	T T N P Design Adjust- Spring housing				- 2/ - 4/								
							A - 1/	Adjustable with tools			A - 5		
For installation		the					A - 2/	Manually	(standard)				
piping syster	n.		•	•	•	•	A - 3/	Adjustable with tools					
Use port R a	lways a	ıs					A - 4/	Manually	Steel ⁶)	R P	R P		
reflow (p _R < 20 bar)							A - 5	Without		AP-14/	AP-34/		
(I-K : : ::.)			•	•			AP-14/	Without check valv	/e		<u> </u>		
							AP-34/	With check valve Coding 41	42 43	' [- -			
							L	Pressure range 5					
								fromto (bar)18		· Hall	P		
								(see also section 5	.1!)	R	R		
Direct mounting at	`	7600)	•	•	•		F	A 1/ to A 4/	Connection	(R) (P)	(R) (P)		
compact hydraulic	MP (D	7200 H) 7900)				•	F	A 13/ to A 43/	block incl. pressure limit-	F, S and L	F1		
power	HCG	(D 7900 G)					F4 5)	A 4 / 1 - A 4 /	ing valve at	(B) R _J · TM	R _T . TM1		
packs 1)	FP (D	7310)	ľ	•			F1 ⁵)		the hydraulic power pack	(R) H			
Mounting	LP (D	7280 H)	•	•			S	A 1/ to A 4/	power pack		¹ M2		
on hydr. power							L ²)	Without DBV		C and D			
packs 1)	Ď	6010 H 6010 DB ⁷)	•	•	•	•	C ²) ³)	A to E		(R)			
		6010 S) ⁷) 6820)			•	•	D 4) 2)	A and B		K and M	P		
Connection	SWR 1	1 (D 7450)	•	•	•		К				(P) — · —		
onto valve banks	SWP 1	I (D 7450)	•	•			М	Without		(P) (R)	(P) : : : : : : : : : : : : : : : : : : :		
		•	•		Р	pressure limiting va	alve	M2					

- Note: Pump delivery flows (dep. on motor speed) must not exceed the max. permissible flow rate of the utilized valve, see D 7470 A/1 sect. 2.1. Note max. pressure p_{max}!
- 2) Not with additional pressure switches acc. to sect. 2.4.3, alternative see section 2.5.2
- 3) Only for tank size B6 ... B40
- 4) Only for tank size B50 and B75
- 5) For accumulator and pressure gauge connections: see also Sk 6900 H(M) as well as Sk 7200 M(N)
- 6) Only in case of pressure surges (> 20 bar) in the return line e.g. as a result of decompression surges from accumulating consumers etc.
 - A return pressure stop (acc. to D 7470 A/1, sect 2.1) might be necessary, (only with BWN(H) 1 or with BWH 2)
- 7) Only type BWH 2(3): Restricted No. of valves at ports P1 and P2 (over size). A separate orientation is to be preferred utilizing BWH 2(3) A-.., when more valves are required in a valve bank
- 8) Figures in brackets apply to directional spool valves, flow pattern symbol W, WX, G, GX
- 9) For combinations of directional spool valves type BWN 1 with BWH 1, see sect. 5.8

2.3 End plate

Coding		Notes	Symbols	Coding 2
On DG	Two DG	(DG stands for pressure switch)	Coding 1	Coding 2
1		Standard	Coding i	
2		With drain valve, e.g. to discharge a connected accumulator (see sect. 5.7)	(R) (P)	(R)
☐1.DG	1.DG	With pressure switch acc. to D 5440 for monitoring the P duct	<u> </u>	
3.		1.DG 2.DG	Coding 33 to 365	Coding 42 to 465
33	3./ 2)	.2 /2 = Without pressure switch, but retrofitting is possible (only with coding 4. and 5. and		
34 35		not with type BWH 3) .3 /33 = DG 33 Adjustm. range: 200 (700) bar	<u>≯</u>	
36	Example:	.4 /34 = DG 34 100 400 bar	(R)	(R) X''
365	33/65	.5 /35 = DG 35 40 250 bar .6 /36 = DG 36 4 12 bar	(P) —	(P)
1.00	4.00	.65 /65 = DG 365		M ⁴ 4
1.DG	1.DG -2.DG	With additional drain valve (ref. to coding 2) and port for pressure gauge connection G 1/4 (see also sect. 5.7)		Coding 4./
4. 42 ¹)	4./ 1) 2)	For DG specification, see coding 3 above.	Coding 3./	DG
43 1)			DG S	No. 1 >
" 465	Example: 42/35			
1.DG	42/03	For type BWN(H) 1:	(R) (P)	(R) X
5. 1)		With additional drain valve (ref. to coding 2.), port for pres-		MATAT
52-	MVP 4	sure gauge G 3/8 and mounted pressure limiting valve type MVP 4 or MVPX 4 acc. to D 7000/1 or D 7000 TÜV (see also	DG No. 2	DG No. 2
"	or MVPX 4	sect. 5.7) Example: 54 - MVPX 4E/150		
565-		For DG specification, see coding 3 above (1.DG).	Coding 52 to 565	
11		Spacers: These spacers enable retrofitting of one (1) or two (2)	<u> </u>	
12 21		valves including their sub-plate (see sect. 3.2 and 4.2). The corresponding coding should be added after the coding	><	
22 31	3./1	of the end plate.		<u></u>
32 41	3./2	Examples: -12	(R):	
42	4./1 4./2	-21 -341-	M4	
51 52	<u>-</u>	-432- -33/652-		
		-42/351- -5652-MVPX4E/150 etc.	Coding1 and2 (space	ers)
			4	
			/ <u> </u>	
			/	


- 1) Only for type BWN 1 and BWH 1
- 2) Version with two pressure switches not with type BWN(H) 1 C, D, S and L or BWH 2(3) C, D. An additional section is available with pressure switch (sect. 2.5.2) as alternative

2.4 Directional valves

2.4.1 Diretional valves type BWN 1 (basic function)

- Coding of the available flow pattern symbols (individual directional valve with corresponding sub-plate = valve section) 1)
- Maximum 10 valves can be combined; Flow pattern symbols J, U, V, L, K, G, and GX are to be counted as 2 valves.
- Idle circulation valves D, F or A should be placed as first valve within the valve bank (first valve coding) to minimize the back pressure.
- Directional valve banks slightly reduce the heat dissipation to the surrounding because of the small distance between neighboring valve solenoids. It is therefore advisable to locate at least one unactuated valve between valves actuated simultaneously or for longer periods. Otherwise neighboring valves would hinder heat dissipation and heat each other up. This rule should be obeyed, when the duty cycle of the valves is above 60% ED.

It is recommended to employ economy circuits acc. to D 7813, D 7832, D 7833, if this is not possible.




- 1) For additional functions, e.g. pressure switches at the consumer port and pressure limiting valves, see section 2.4.3 and 2.5 ++
- 2) Observe flow resistances in sect. 5.6! Permissible pump delivery flow approx. 0.5 x Q_{max}

- 3) For release ratios and further notes see sect. 5.4
- 4) For detailed symbol ref. to sect. 5.3

2.4.2 Directional valves type BWH 1, BWH 2 and BWH 3


- Coding of the available flow pattern symbols (individual directional valve with corresponding sub-plate = valve section) 1)
- Maximum 10 valves can be combined; Flow pattern symbols J, U, V, L, and K are to be counted as 2 valves.
- Idle circulation valves D, F or A should be placed as first valve within the valve bank (first valve coding) to minimize the back pressure.
- Directional valve banks slightly reduce the heat dissipation to the surrounding because of the small distance between neighboring valve solenoids. It is therefore advisable to locate at least one unactuated valve between valves actuated simultaneously or for longer periods. Otherwise neighboring valves would hinder heat dissipation and heat each other up. This rule should be obeyed, when the duty cycle of the valves is above 60% ED.

It is recommended to employ economy circuits acc. to D 7813, D 7832, D 7833, if this is not possible.




Directional valves with additional return pressure stop (not available with type BWH 3!):





When several valves are operating in parallel, an return pressure stop is required sometimes. It prevents pressure surges out of the common return pipe from entering unoperated, unloaded or easily moving consumers, whenever there is a connection $A{\to}R$, thus preventing uncontrolled movements.

These check valves are unsuitable to block pressurized fluid, which might be apparent at R, depending on the operation sequence with other valves. A circuit with an external check valve would have to be employed instead.



2.4.3 Directional valves with integrated additional elements

Pressure switches (DG 33, DG 34, DG 35, DG 36 oder DG 365 nach D 5440) at ports A, B, and P Not available for directional spool valves coding W(WX) and G(GX) acc. to sect. 2.4.1!

Mounted pressure switch

Position	Coding	Suite	d fo	r	DG	'
		BWN 1 BWH 1	BWH 2	ВМН 3		range
	2	•				Prepared for retrofitting
At port A or B	3	•			33	200 (700) bar ¹)
/ Col B	4	•	•	•	34	100 400 bar
	5	•	•	•	35	40 250 bar
	36	•	•	•	36	4 12 bar
	364	•	•	•	364	4 50 bar
	365	•	•	•	365	12 170 bar
At port	62	•				Prepared for retrofitting
' -)	6	•			33	200 (700) bar ¹)
	7	•	•		34	100 400 bar
	8	•	•		35	40 250 bar
	66	•	•		36	4 12 bar
	664	•	•		364	4 50 bar
	665	•	•		365	12 170 bar

Can't be combined with directional seated valves, coding D, A, F, P, O, I, Y or valve banks BWN(H)..C (D, S, L) as well as 1. valve within valve bank BWN(H) 1(2) P!

Note

Available version: directional seated valves, coding H, M, N and R. Makes end plates coding 33 ... 365 superfluous. Can't be combined within valve bank BWN(H)..C (D, S, L) or as 1. valve within valve bank BWN(H) 1(2) P!

Order examples:

3/2-way directional valve with one DG at port A:

BWN1A-**H4**-1-1-G 24

3/2-way directional valve with return pressure stop and one DG in the pump gallery:

BWH1F-H18 R166 -1-1-G 24

4/3-way directional valve with two DG at ports A and B BWH2A-**K4 5**-1-1-G 24

> DG at port A DG at port B

1) Makes only sense in combination with BWH 1

Attention:

Do not exceed p_{max}! Observe perm. pressure for BWN 1 (acc. to D 7470 A/1 sect. 2.2.2).

Valve type, available versions (codings) and symbols (examples)

vaive type, availa	Die versions (codi	rigs) ariu syiri	bois (examples)					
2/2-way	3/2-wa	ay		4/2-way	3/3-w	ay	4/3-wa	y
2 B 3 C 4 E 5 Q 36 65	H M N R	2 3 4 5 36 65	62 6 7 8 66 665	y 2 ST 3 4 5 36 65	J.: 3 4 5 36 65	V 2 U.: 3 4 5 36 65	2 L 3 4 5 to 36 d. 65	Y 2 K 3 4 5 36 65
(R) A X X X X X X X X X X X X X X X X X X		OG at port P	With DG and return pressure stop		Example:	J 36	Example:	K 4 3

3/2-way directional valve with a DG at port A

For technical data of the pressure limiting valve, see D 7000 E/1, type MVF 4..

BWH1A-1/200- **M/150 J/100** - 1-1-G 24

Order example: Basic type coding acc. to section 2 ++ 3/2-way directional seated valve -Pressure specifica-(acc. to sect. 2.4.1 and 2.4.2) with tion (bar) for the presintegrated pressure limiting valve 2): sure limiting valve

H(1)/...; M(1)/...; N(1)/...; R(1)/...; J(1)/...; U(1)/...; V(1)/...

Flow pattern symbol acc. to the order example

2) When used as second pressure stage, available with tapped plug at port A. When ordering, indicate in uncoded text: e.g. BWN1A-1/200-M/150 RH/100-1-1-G 24 with tapped plug No. 2749 003 at the third valve section (coding H/100). With coding H(1), M(1), N(1), R(1) a combination with pressu switches is not available. Not available in combination with valve bank BWN(H) 1C (S, L)!

Version with pressure limiting valve and pressure switch at port A (only for type BWN 1 and BWH 1)

For technical data of the pressure limiting valve type MVF 4.., see D 7000 E/1 or for the pressure switch type DG.., see D 5440

Order example: BWH1A5 - H **J4/250** - 1-1-G 24

Basic type coding acc. to section 2 ++

Symbols (examples)

ification (bar)

3/3-way directional seated valve — (acc. to sect. 2.4.1 and 2.4.2) with directly mounted pressure limiting valve and pressure switch:

J2 (3, 4, 5, 36, 65) /...

U2 (3, 4, 5, 36, 65) /...

V2 (3, 4, 5, 36, 65) /...


Pressure specification (bar) for the pressure limiting valve

Attention:

Not available in combination with valve bank BWN(H) 1 C(S, L)!

Only available as 1. valve within a valve bank BWN(H) 1P -.. with coding J2/.. or U2/..!

J4/250 U1



2/2-way directional seated valve with miniature pressure limiting valve (only for type BWN 1 and BWH 1)

Intended use: For arbitrary activation of various pressure stages in pre-control circuits or other hydraulic circuits with low pump delivery flow.

Order example:


BWN1A5 - F/80 F/180 F/300 -1-1-G 24

Basic type coding acc. to section 2 ++

2/2-way directional seated valve (acc. to sect. 2.4.1 and 2.4.2) with integrate pressure limiting valve

F/... Operation pressure p_{max} = 320 bar **D/...** Flow = approx. 2 lpm

Pressure specification (bar) for the pressure limiting valves



Flow pattern symbol corresponding to

2.5 Additional sections

2.5.1 Pressure reducing valves as additional section (only type BWN 1, BWH 1 and BWH 2)

Max. permissible inlet pressure 400 bar

They can be placed arbitrarily within the valve bank. The pressure reducing valve determines the pressure for all directional valves mounted downstream (secondary side) and the consumers connected to them, independent from simultaneous withdrawal of pressurized oil with a higher pressure level via directional valves located upstream (primary side).

Example: Clamping cylinders with low pressure setting or piloting valves for electro-hydraulic low-pressure remote control purposes.

The pressure reducing valves type CDK 3 (acc. to D 7745) are used here. These valves do not show any leakage in blocked state (pressure upstream is higher than the set secondary pressure) as they are designed as 2/2-way valves, acting like a seated valve.

BWN 1 - CZ5/130

A check valve prevents any reflow from the secondary side to the primary side (pump side) or any pressure drop. It is necessary to install a pressure limiting valve in the consumer pipe if externally induced loads could cause unpermissible peak pressure. For old version with 3-way pressure reducing valve, see sect. 4.4.

/5R /7

Order examples: BWN 1 A-1/120- CZ2/180/5R/4-HH-1-G 24

For individual order (example) e.g. as spare part, retrofitting, own storage etc.


55/...

			'							
2-way pressure reducing valve 1)										
Codir	ng	Utilized pressure reducing valve	Pressure range (bar) ²)							
	Х	without ⁴)								
	08/	CDK 3-0,8	50 450							
- CZ	1/	CDK 3-1	30 300							
	2/	CDK 3-2	20 200							
	5/	CDK 3-5	15 130							
	25/	CDK 32-5 ⁵)	8 130							


CDK 35-5 5)

Pressure switch DG 3.. acc. to D 5440 (no coding) Without pressure switch 6) DG may be retrofitted /3 DG 33 200 ... (700) bar ³) /4 100 ... 400 bar DG 34 DG 35 /5 20 ... 250 bar DG 36 /6 4 ... 12 bar /7 DG 365 12 ... 170 bar

5R Check valve in gallery P



Coding - CZ 08 to 55/..



Version with DG.. see order example above

 Only tool adjustable available. Adjustment can be altered (monitored by a pressure gauge) after slackening the lock nut with a spanner a/f 17


15 ...130

- 2) Set value for secondary pressure (pressure gauge reading) at flow Q = 0 lpm (consumer in end position). The pressure drops a little, if pressurized oil flows to the consumer.
- 3) Use of this version doesn't make much sense due to the high primary side pressure.
- 4) With tapped plug, prepared for retrofitting of a CDK 3(32, 35)-..
- 5) For details, see D 7745
- 6) Not with type BWH 2

Symbol

2.5.2 Individual sub-plate with pressure switch (for type BWN 1, BWH 1 and BWH 2)

When it isn't possible to install a pressure switch at the end plate e.g. when there is not enough space, it can be mounted on an individual sub-plate at any position within the valve bank.




Prepared for retrofitting of a pressure switch, only avail. for type BWN 1 and BWH 1

2.5.3 Directional valve coding H with return pressure stop and pressure switch (only type BWN 1 and BWH 1!)


The directional seated valve represented in the symbol allows arbitrary blocking of the pump gallery. A return pressure stop is additionally integrated in the pump gallery.

Order example: BWN1A-1/150 - **H8XX** NN-1-1-G 24



2.5.4 Separation plate for P duct (for type BWN 1 and BWH 1!)

When due to functional reasons two separate control circuits are intended (e.g. independent flow or pressure figures), a space saving layout can be achieved with this separation plate, still using one joint return duct. The use of an end plate featuring a pressure gauge port M4 (e.g. coding -42) is recommended, as this may be utilized as secondary pressure inlet.




3. Unit dimensions


All dimensions are in mm, are subject to change without notice!

3.1 Connection blocks and adapter plates acc. to section 2.2

3.1.1 Connection blocks




Type BWN(H) 1 AP 1 and BWN(H) 1 AP 3



3.1.2 Adapter plates

The illustration below shows lateral installation e.g. with hydraulic power packs type MP (acc. to D 7200 H) or hydraulic power packs (acc. to D 6010 H).

The photo on the cover page illustrates erect installation with compact hydraulic power packs type HK (acc. to D 7600-..), HC (acc. to D 7900) or HCG (D 7900 G).




Note: Port R (G 1/4, BSPP) may be used as additional reflow port.

Pressure port M, M1 and M2 (G 1/4, BSPP) e.g. for connecting a pressure gauge or a pressure switch


Type BWN(H) 1 S


Adapter plate for direct mounting onto hydraulic power packs type LP, acc. to D 7280 H



Note: Port R (G 1/4, BSPP) may be used as additional reflow port.

Pressure ports M (G 1/4, BSPP) e.g. for connecting a pressure gauge or a pressure switch







Type	a ₂	b ₃	С	е
BWH 2 C	30	15	23	9
BWH 2 D	26	20	20	5
BWH 3 C	37	20	29	9
BWH 3 D	26	30	25	5

Type BWN(H) 1 L

Adapter plate for direct mounting onto hydraulic power packs type LP, acc. to D 7280 H




Type BWH 2 F BWH 3 F




								(BSPP)
Type	а	a ₁	b	b ₁	b_2	h	h ₁	M1, M2 and R
BWH 2 F	50	25	25	14	10	50	10	G 1/4
BWH 3 F	62	30	30	15	15	60	12	G 3/8

Note:

Port R (G 1/4, BSPP) may be used as additional reflow port. Pressure ports M 1(2) e.g. for connecting a pressure gauge or a pressure switch




Coding P
(Illustration with type BWHN(H) 1)



3.2 End plates acc. to section 2.3


Coding

(Illustration with type BWN(H) 1 but applies to all sizes) Coding



Coding


Coding




Coding **52** ... **565-MVP...**

(only with type BWN(H) 1!)

Ports M4, ISO 228/1 (BSPP): G 1/4 (Coding 42 ... 465) G 3/8 (Coding 52 ... 565)





1) with MVPX 4... (lead sealed)


Suited for	L	L ₁	а	a ₁	a_2	b	b ₁	b_2	b_3	С	C ₁	c ₂	е	e ₁	e ₂	e_3	f	i	g
BWN(H) 1	59	97	10	12	36	5	8	31	22.5	20	36	20	11	4	16	9.5	21	18	M 6, 6 deep
BWH 2	53	91	12	12	38	6	6	32	27	25	25	25	8.5	8.5	8.5	10	15	20.5	M 6, 6 deep
BWH 3	65	115	16	16	35	8	8	27	26	36	36	35	8	8	8	9	14	35	M 8, 8 deep

3.3 Directional valves

3.3.1 Basic functions acc. to section 2.4

Directional seated valves and directional spool valves for type BWN(H) 1


(Version with return pressure stop is identical)



Manual emergency actuation M 6, 6 deep

Valve sections

Coding K



 œ to	œbo	<u> </u>
		Ì


Coding	а
D, F, H, M, N, R	23.5
B, C, Q, E	15
P and O	21.5
J and U	57
G and GX	50


Ports ISO 228/1 (BSPP): A, B, P and R = G 1/4

 This dimension depends on the manufacturer and can be max. 40 mm acc. to DIN EN 175 301-803

Directional seated valves for type BWH 2


(Version with return pressure stop is identical)





Ports ISO 228/1 (BSPP): A, B, P and R = G 1/4

Manual emergency actuation




Manual emergency actuation


1) This dimension depends on the manufacturer and can be max. 40 mm acc. to DIN EN 175 301-803

3.3.2 Additional functions

Directional seated valves with additional pressure switches for type BWN 1 and BWH 1, 2, and 3 acc. to section 2.4.3 (Version with return pressure stop is identical)




Directional seated valves with pressure limiting valve for type BWN 1 and BWH 1 acc. to section 2.4.3



3.4 Additional sections acc. to section 2.5


2-way pressure reducing valve type -CZ ..., for installation in valve banks type BWN 1, BWH 1, and BWH 2 (acc. to section 2.5.1)



switch (acc. to sect. 2.5.2)

pressure stop and pressure switch (acc. to sect. 2.5.3)

Separating plate for gallery P (acc. to section 2.5.4)



4. Additional elements


4.1 Orifice inserts (only type BWN 1 and BWH 1!)

When an orifice is required for functional reasons at the entries of valves B, P, I, C, O, Y, H, M, S and T, then it must be stated in uncoded text which valve (coding and position number starting from the connection block) should be fitted with which orifice. Currently available \emptyset 0.7 (for retrofitting order No. 7470 040)

Example: BWN1A-5-FHHJ-1-1-G 24;


Valve H, section 2 with orifice Ø0.7






4.2 Directional valve section

For retrofitting within directional valve banks e.g. instead of the clearance with end plates 11, 12, 21, 22 etc. (sect. 2.3). In case of further extension, a tension rod can be ordered according to the new number of valves.





Valve section to be installed by the customer

Installation directions:

- 1. Remove cap nut with seals and end plate from the tension rod
- 2. Thread on valve section
- 3. Push on end plate with USIT-ring and tighten cap nut with 25 Nm.

One USIT-ring and the tubular spacer will no longer be needed.


	BWN(H) 1	BWH 2	BWH 3	1) With end plate
① O-ring NBR 90 Sh	Ø5x1.5 and Ø11x1.5	Ø6.07x1.78	Ø10.82x1.78	coding 12 (22, 332 etc.) two tubular spacers 4
② Cap nut	HAWE-Nr. 7250 015 Max. torque 20 Nm	ISO 4032-M8-8-A2K Max. torque 40 Nm	ISO 4032-M12-8-A2K Max. torque 80 Nm	with USIT-ring in between 3
USIT-ring washer	U8.7x16x1	ISO 7092-8.4-140HV-A2K	ISO 7092-13-140HV-A2K	
4 Tubular spacer	HAWE-No. 7250 041	HAWE-No. 7250 041	HAWE-No. 7287 041	

4.3 Blanking plate

An already assembled sub-plate with blanking plate can be used instead of a clearance (see sect. 2.3 end plates) for valves to be retrofitted. They can be fitted anywhere within the valve bank. An X is appended to the code lette (section 2.4.1 and 2.4.2) of the directional control valve to be retrofitted. The following are available: HX, MX, NX, RX, BX, CX, EX, QX, PX, OX, YX, IX, SX, TX and AX. A combination with pressure switches acc to sect. 2.4.3 is possible.

Example: BWN1A-1/200-FHHX-1-1-G 24

Not available for directional spool valves W and G. (Coding WX and GX do have a different meaning, see section 2.4.1).



Necessary parts:

/	BW	/N 1 and BWH 1	BWH 2	BWH 3			
	1	Blanking plate 7470 057	1 Blanking plate 7586 033	1 Blanking plate 7587 037			
	3	O-rings 6x1.5 NBR 90 Sh	complete	complete			
	4	Screws ISO 4762-M4x16-8.8-A2K					
		Height 10 mm	Height 10 mm	Height 12 mm			


4.4 3-way pressure reducing valve for BWN(H) 1 and BWH 2 (Production is running out)

Permissible inlet pressure 300 bar

Order example: BWH 2 A-2/100-HR **Z5** ²) -HH-1-G 24

Pressure range (bar) adjustable	Standar version	d	With a 2/2-way seated valve Special version WN 1 D WN 1 F				e upstream WH 2 D WH 2 (WH 1 D) (WH 1				Vers. Z11 to Z48 with add, pressure switch	
from to ¹)	Tool ad- Manually justable adjustable		Tool ad- Manually		Tool ad- Manually		Tool ad- Manually		` '		acc. to D 5440 ³)	
160 250	Z1	Z 5	Z11	Z 15	Z 21	Z 25	Z 31	Z 35	Z41	Z 45	Z114 Z484 with DG 34	
60 160	Z 2	Z 6	Z 12	Z 16	Z 22	Z26	Z 32	Z 36	Z 42	Z 46	Z115 Z485 with DG 35	
30 120	Z 3	Z 7	Z13	Z 17	Z23	Z 27	Z 33	Z 37	Z 43	Z 47	Z116 Z486 with DG 36	
10 30	Z4	Z 8	Z14	Z 18	Z 24	Z2 8	Z 34	Z 38	Z 44	Z 48	Z1165 Z4865 with DG 365	
Symbols (R) (P) Tool ad- justable (A) (R) (P) Manually ad- justable (A)	(R) (P)	X M				M					R P X S W.	

- 1) Set value for secondary pressure (pressure gauge reading) at flow Q = 0 lpm (consumer in end position). The pressure drops a little if pressurised oil flows to the consumer.
- As single unit for own storage, replacement, etc. order code is:
 BWN 1 and BWH 1: ADZ1-Z1 (to Z28; resp. Z114 to Z2865) G12(24) or ...- WG 230
 BWH 2: ADZ2-Z1 (to Z8; Z31 to Z48 resp. Z314 to Z4865) G12(24) or ...- WG 230, see above
- 3) For adjustment ranges see above. Monitoring of the pump sided (primary) P duct.
 Note: Version Z1 ... Z8 can't be used with pressure switch, as the leakage oil consumption would lead to the permanent on/off switching of the pump being controlled by the DG...



5. Appendix

5.1 Connection block with proportional-pressure limiting valve type AP

Proportional pressure limiting valves type PMVP 4 (acc. to D 7485/1) are utilized here, for control characteristic etc. see D 7485/1. The electric control requires a prop. amplifier e.g. EV1M2 acc. to D 7831/1 or EV1G1 acc. to D 7837.


Available output voltage 12 V DC or 24 V DC, this voltage is usually identical to the solenoid voltage of the directional valves. Otherwise this has to be stated in the order coding.

The minimal pressure setting is 5 bar due to functional reasons (control of the piloting section). This min. figure may be raised via a set screw.

Order example: BWH 1 AP - 13 - 43/420 - HH - 1 - 1 - G24

5.2 Fitted screen filters as standard


To prevent sudden disturbance caused by coarse contaminations that may occasionally be carried along in the oil (such as torn off particles of tubing, packing, scale, swarf) directional seated valves are fitted with screen filter elements 0.25 mm mesh width in the ports P and A. The directional spool valves cannot be fitted in the housing with these filter elements because of the port design, but they are less sensitive to the contaminations mentioned above.



These screen filter elements should not be seen as a replacement for the usual hydraulic filters. In practice, however, they provide sufficient protection against malfunctions in small hydraulic systems. When such malfunctions should occur, the filter elements should be checked first. For the sake of simplicity, the filter elements are not explicitly shown in the diagrams.

5.3 Detailed symbol for spool valve G(X) c (for type BWN 1)

The G(X) spool valve of BWN 1 valve banks consists of two 3/3-way spool valves. Whenever one valve is actuated by the solenoid, it will actuate mechanically the other valve via a lever



5.4 Release ratios with spool valve (for type BWN 1 and BWH 1)

Max. flow Approx. 5 lpm (BWN 1)

Approx. 8 lpm (BWH 1)

Control pressure p_{St} Min. pressure in the P duct (guideline)

For releasing $p_{St} = a \cdot p_{A(B)} + 6$ (bar)

For keeping open $p_{St} = \Delta p_{A(B) \to R} + \Delta p_R + 10$ (bar)


 $a = \frac{1}{2.67}$ Release ratio

p_{A(B)} Pressure at port A(B) in closed state

 $\Delta p_{A(B \to R} \quad \text{See } \Delta p\text{-Q-curves}$

 Δp_{R} When flow resistance occurs from the

valve to the tank



Oil viscosity during measur. approx. 60 mm²/s


There is also a release ratio of 1:3.8 available. Indicate in uncoded text, if this is required.

Example: BWH1 A-5-HKR-1-1-G 24 valve K with release ratio 1:3.8

5.5 Installation instruction

5.5.1 Check valve insert EK 01

Only for WN 1 type valves coding Q and N acc. to sect. 2.4.1



Due to the O-ring's elasticity, the check valve may move and protrude a few tenths of a millimetre before being bolted to the sub-plate. If the valve WN 1 is filled with oil (e.g. due to functional test on a test rig previously), tightening of the bolts may cause a compression of the trapped oil due to the check valve being forced in. The resulting pressure would exceed the one at which the solenoid is still able to actuate. While tightening the mounting screws, it is therefore advisable to press either the manual emergency actuation (D 7470 A/1, see sect. 4.1) or energise the solenoid via the valve. This problem cannot occur with WH 1 type valves due to the hydraulic relief.

5.5.2 Solenoid heat built-up

Directional valve banks slightly reduce the heat dissipation to the surroundings because of the small distance between neighbouring valve solenoids. It is therefore advisable to locate at least one unactuated valve between valves actuated simultaneously or for longer periods. Otherwise neighbouring valves would hinder heat dissipation and heat each other up. This rule should be obeyed, if the duty cycle of the valves is above 60% ED.


If this is not possible it is recommended to use economy circuits acc. to D 7813, D 7832, D 7833.


5.6 Flow resistance for WN 1 - or WH . L - valve

(acc. to sect. 2.4.1 and 2.4.2)

This valve is used for the control of double acting hydraulic cylinders e.g. acc. to DIN ISO 7481 with unequal piston areas when arbitrary stop is required at any lift position.

Permissible pump delivery flow approx. $0.5 \times Q_{\text{max}}$





Oil viscosity during measurement approx. 60 mm²/s

Flow resistance, related to inlet P:


Cylinder extended $\Delta p = \ \Delta p_{P(B) \to A}$ can be read directly from $\Delta p\text{-}Q\text{-}curves$

using
$$Q = Q_P + Q_{B \to A} = Q_P \cdot \left(1 + \frac{1}{\frac{A_1}{A_3} - 1} \right)$$

Cylinder retracted $\Delta p = \Delta p_{P \to B} + \Delta p_{A \to R} \cdot \frac{A_1}{A_3}$ Can be read using $Q = Q_P \to Q_P \to Q_P$

hydraulic accumulator

5.7 Application example for end plates with release valve acc. to section 2.3



1) The unit approved accumulator safety valve secures the hydraulic accumulator against unpermissible excess pressure. Supplied with fixed pressure setting and lead seal e.g. at the highest permissible accumulator pressure p₄ or a pressure p_{3 max} that is still permissible for the hydraulic system. The adjustable limit for the max. operating pressure p₂ or p_{2 max} intended for the hydraulic system is normally achieved by the operating pressure limiting valve, shut-off valve (e.g. D 7529, D 6170-ALZ) or other devices (e.g. pump cut-off or pump idle circulation activated by a pressure switch).

5.8 Combination of directional valves of type BWN 1 with BWH 1

A combination of these two basic types is possible, but the permissible operation pressure for the respective basic type and flow pattern symbol have to be taken into account.

Order examples:

- One or several WH valves within a BWN valve bank BWN/H1A-5 - MR/NQ/HT -1-1-G 24
- One or several WH valves at the end of a BWN valve bank BWN/H1A-1/120 - MRHT/NN -1-1-WG 230
- One or several WN valves at the end of a BWH valve bank (it is then regarded as a valve bank type BWH).
 BWH/N1A-2/220 NJ/HH -1-1-G 24
- One or several WN valves together with an upstream located -CZ../... (sect. 2.5) at the **end** of a BWH valve bank BWH/**N**1A-1/300 HR/**CZ 2/180 HM** -1-1-G 24.

CZ../... is then regarded as part of the WN part of the valve bank, therefore its coding is located after the slash. Observe the permissible inlet pressure, see section 2.5!

6. Mass (weight) approx. in kg, individual elements

Connection blocks acc. to section 2.2

Coding	A1/ to A4/	5	F	F1	С	D	K	М	Р	AP
BWN(H) 1	0.4	0.2	0.4	0.5	0.5		0.5	0.5	0.6	1.3
BWH 2	0.5	0.5	0.4		0.5	0.6	0.6		0.6	
BWH 3	0.8	0.5	0.8		0.5	0.8				

End plates acc. to section 2.3

Coding	1 a. 2	11	12, 21 and 22	33 to 365	3/3	42	43 to 465	4/3	52	53 to 565	with pressure limiting valve 53 MVP(X)4E/
BWN(H) 1	0.1	0.1	0.2	0.5	0.8	0.3	0.6	0.9	0.4	0.8	1.0 (1.3 with DG)
BWH 2	0.1	0.2	0.2	0.6	0.9		0.6	0.9			
BWH 3	0.3	0.5	0.8	1.0	1.3		1.0	1.3			

Directional seated valves acc. to section 2.4.1, 2.4.2 and 2.4.3

Coding	acc. t	o section 2.4.	1 a. 2.4	4.2. No	te: B1	. C1 e	tc. ide	ntical	acc. to section 2.4.3 (additional elements)			
	А	B, C, D, E, F, H, M, N,	J and	G and	Y and	W and	K	L			with pressure lim H(1)/; M(1)/	iting valve J/; J1/
		O, P, Q, R	U	GX	I	WX			with1 DG	with 2 DG	. , , ,	U/; U1/
BWN(H) 1	0.9	0.8	1.6	1.6	1.0	1.0	2.0	1.8	+ 0.3	+ 0.6	1.1	1.7 (2.0 with DG)
BWH 2	1.0	0.9	1.8		1.1			2.0	+ 0.3	+ 0.6		
BWH 3	2.0	1.9	3.5		2.4			4.2	+ 0.3	+ 0.6		

Pressure reducing valves acc. to section 2.5.1 and 4.4

Coding	- CZ X	- CZ 08/	Z1	Z11	Z114
		to	to	to	to
		- CZ 55/	Z8	Z48	Z4865
BWN(H) 1	0.5 (0.7) 1)	1.2 (1.4) 1)	0.9	1.5	1.8
BWH 2			0.9	1.5	1.8

1) Figures in brackets = with DG

Additional elements

Coding	Directional seated valve with pressure limiting valve (sect. 2.4.3)	Sub-plate with DG (sect. 2.5.2)	Directional seated valve with return pressure stop and DG (sect. 2.5.3) H6(7, 8)XX	Separation plate (sect. 2.5.4)	Blanking plate (sect. 4.3)
BWN(H) 1	1.3	0.4	1.3	0.1	0.1

7. Type over view Order example: - 33 / 652 - 1 - G 24 BWN1 A-1/300 - H1/250 M3 - CZ1/180/5R/4 - WX **BWH2 F** - J4/250 N3 HHHR-1 - 1 - WG 230 Order example: G 12, G 24, WG 110, WG 230 (for other voltage see D 7470 A/1 sect. 2.2.2) Ports acc. to ISO 228/1 (BSPP) G 1/4 (BWN(H) 1 and BWH 2) G 3/8 (BWH 3) End plate (additional elements, see sect. 2.3) **3, 4, 5, 6, 65** 1. Pressure switch (DG 3. acc. to D 5440) (with end plates 3, 4 and 5 only) /33, /34, /35, 2. Pressure switch (DG 3. acc. to D 5440) /36, /65 (with end plates 3 and 4 only) 2 and /2 1) Prepared for retrofitted mounting of the 1. or 2. pressure switch (with end plate 4 and 5 only) 1 and 2 Clearance for 1 or 2 valves (tubular spacer) MVP4.. and Mounted pressure limiting valve **MVPX4..** 1) (types MVP 4 or MVPX 4 acc. to D 7000/1 or D 7000 TÜV, only with end plate 5) End plate (see sect. 2.3) Standard End plate with discharge valve 2 3 End plate with one or two pressure switches 4 End plate 3, with additional drain valve 5¹) End plate with one pressure switch and mounted pressure limiting valve Valve sections - additional elements (see sect. 2.4.3, 2.5.3 and 2.5.4) Return pressure stop 2 and 62 1) Prepared for retrofitted mounting of a pressure switch (DG in the consumer or pump duct) 3 1), 4, 5, 36, 65 Pressure switch (DG 3.. acc. to D 5440) in the consumer duct Pressure switch (DG 3.. acc. to D 5440) in the pump duct 6, 7, 8, 66, 665 **XX** 1) Added to the coding for pressure switch (coding 6...665), shut-off valve acc. to sect. 2.5.3 /.. 1) Pressure limiting valve with pressure specification in the consumer duct Blanking plate (sub-plate without valve, acc. to sect. 2.5.4) Valve sections / flow pattern (see sect. 2.4.1, 2.4.2, 2.4.3, 2.5 ++ and 4.4) D, F, B, Q, A, C, P, O 2/2-way function (seated valve) 2/2-way function (seated valve with pressure limiting valve, sect. 2.4.3) F/.., D/.. 1) H, N, M, R, I, Y 3/2-way function (seated valve) W, WX 4/2-way function (directional spool valve, with type WN 1 only) S, T 4/2-way function (seated valve) J, U, V 3/3-way function (combination of two seated valves) 4/3-way function (combination of two seated valves) L K 4/3-way function (combination of two seated valves) with shut-off valves, two pressure switches available) G, GX 4/3-way function (directional spool valve, with type WN 1 only) -CZX 3) Pressure reducing valve acting for system downstream (with/ -CZ08 to CZ55/.. 2) without shut-off valve, with/without pressure switch, adjustable manually or with tools, several pressure ranges) Pressure reducing valve (running out of production, see sect. 4.4 Z1.. to Z8.. 2) -3.- to -65- 1) Pressure switch on individual sub-plates within the valve bank, sect. 2.5.2 -X- 1) separating plate acc. to sect. 2.5.4 Connection blocks for pipe mounting (see sect. 2.2) A-1/.., A-2/.. With pressure limiting valve (adjustable with tools or manually) with pressure specification A-3/.., A-4/.. With pressure limiting valve (adjustable with tools or manually) with pressure specification (steel housing) Without pressure limiting valve A-5 AP-.. 1) With prop. pressure limiting valve (sect. 5.1) Adapter plates for mounting onto hydraulic power units (sect. 2.2) F, F1 ¹) For types HC (D 7900), MP (D 7200 H), FP (D 7310) and HK (D 7600...) **S, L** ¹) For type LP (D 7280 H) For types R (D 6010 H ++) and Z (D 6820) C Adapter plates for mounting onto directional valve banks (sect. 2.2) **K**²), **M**¹), **P**²) For types SWR 1 or SWP 1 (D 7450) or BVZP 1 (D 7785 B) 1) Not available for BWH 2, BWH 3 Basic type coding and size (see sect. 2.1 Table 1) Not available for BWH 3

BWN 1, BWH 1, BWH 2, BWH 3 (size 1, 2 and 3)

Only size 1: Combination types available BWH/N 1 or BWN/H 1 (see sect. 5.8)

With tapped plug, prepared for retrofitting of a CDK 3-..